688.425 **CONTACT GRILL -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-GH813P2K-001	Operation Handle Complete	2
2	Z-GH813P2K-002	Top Cover Board	2
3	Z-GH813P2K-003	Upper Heating Element Plate	2
4	Z-GH813P2K-004	Upper Heating Element	2
5	Z-GH813P2K-005	Upper Module Plate	2
7	Z-GH813P2K-007	Coil in Pipe-Right	1
8	Z-GH813P2K-008	Column Cover	2
9	Z-GH813P2K-009	Rear Rotary Axle	2
10	Z-GH813P2K-010	Twisting Spring	2
11	Z-GH813P2K-011	Copper	2
12	Z-GH813P2K-012	Power Cord	2
13	Z-GH813P2K-013	Temperature Limiter	2
14	Z-GH813P2K-014	Heat Insulation	2
15	Z-GH813P2K-015	Terminal	2
16	Z-GH813P2K-016	Bottom Plate	1
17	Z-GH813P2K-017	Oil Tray	2
	Z-GH813P2K-018	Thermostat (EGO)	2
19	Z-GH813P2K-019	Knob Of Temperature Controller	2
20	Z-GH813P2K-020	Indicator Lamp-Yellow	2
	Z-GH813P2K-020-1	Indicator Lamp-Green	2
21	Z-GH813P2K-021	Boarding	1
22	Z-GH813P2K-022	Feet	4
23	Z-GH813P2K-023	Handle	2
24	Z-GH813P2K-024	Coil in Pipe-Left	1
25	Z-GH813P2K-025	Lower Module Plate	2
26	Z-GH813P2K-026	Lower Heating Element	2
27	Z-GH813P2K-027	Lower Heating Element Plate	2
28	Z-GH813P2K-028	Orb	4